



TEL: 773-341-3030  
FAX: 773-341-3046  
TOLL FREE: 1-800-465-2736  
WEBSITE: [www.mifab.com](http://www.mifab.com)

---

**Recommended Excavation, Backfilling, and Finishing for  
Interior or Exterior Below Grade  
Big Max Interceptors**

- A. Install the interceptor(s) as close as practical to the fixtures being served.
- B. The excavation must be a minimum of 12" greater on all sides of the tank.
- C. The depth of the excavation must be greater than 6" on the bottom of the interceptor.
- D. Fill the interceptor with water prior to backfilling in order to prevent the interceptor from floating.
- E. Fully install the double wall corrugated pipe and lid prior to backfilling.
- F. Concrete or finishing material requirements is to be determined by the specifying engineer.
- G. Encase the interceptor in well-packed ¾" rock, or sand.
- H. To prevent float out; the Anchor kit is recommended for installations in high water table conditions. This is to be determined by the specifying engineer.