

MI-SAND Series - Owner's Maintenance Guide

The MIFAB sand interceptors should be cleaned once a month to prevent solids and or sludge from discharging into the sewer system. The wastewater entering the interceptor usually contains some solids that settle to the bottom.

INITIAL START-UP PROCEDURE

1. Remove the lid.
2. Inspect inside of interceptor for any foreign materials left inside during installation and remove all such materials.
3. Replace the lid and tighten the heavy duty bolt in the center.

CLEANING THE MIFAB SAND INTERCEPTOR

1. The solids / sludge must be removed from the bottom of the interceptor during every cleaning.
2. Inspect the cover gaskets and replace if needed.
3. A regular cleaning cycle must be established and maintained to assure maximum operating efficiency of the interceptor.

HOW TO REPLACE THE GASKET

1. Remove the lid(s)
2. Remove old gasket from the body of the interceptor.
3. Install new gasket. Ensure that the corners are filled it to have a leakproof and an air tight fit.
4. Replace the lid and tighten the heavy duty bolt in the center.